**Messenger+
Flowing Gas:
AutoPark Service Election Overview**

AutoPark Service Election Overview

An **AutoPark** nomination will automatically be generated to provide the balancing nomination for an out of balance pool:

- ✓ If parking and/or unparking quantities are available and
- ✓ If the pooling shipper has elected to participate in AutoPark Service

Note: To participate in Pool AutoPark Service a pooling shipper will need to have an associated GPS AutoPark contract.

The **AutoPark Service Election screen:**

- ✓ Shows if the Pipeline is allowing Due Pipe and Due Ship nominations
- ✓ Allows the pooling shipper to turn on/off AutoPark Service Participation

AutoPark Service Election Overview, Cont.

1. To access the **AutoPark Service Election** go to the **Customer Activities Menu** ☰ .

2, 3 & 4. Select **Flowing Gas**, **Auto Pool Balancing**, and **AutoPark Service Election.**

AutoPark Service Election Overview, Cont.

ENERGY TRANSFER

5. Select the **Effective Date**.

6. Click the **RETRIEVE** button.

7. The **Payback Limits Section** informs whether the pipeline is allowing **Due Pipe** or **Due Ship Nominations**.

8. The **AutoPark Service Election**:
   - Allows the user to elect to participate or not to participate in the **AutoPark Service.**
   - Displays the Pipeline limits on park/unpark.

ℹ The **Participate** election will go into effect the next cycle after the change is made and will remain in effect until a new change is submitted.

9. Click the button.